

# Cyclopital3D

## Update Procedures for PMP units using Windows XP OS (10/09)

### Firmware Upgrade Steps:

1. Download update files and USB drivers to your computer
2. Load updated files to PMP unit #1 and PMP unit #2
3. Restore default setting in PMP units

### Download upgrade files and USB drivers to your computer:

For Windows **XP** Operating System (OS)

1. Create a new folder on your computer called "Cyclopital3D" for saving this and future upgrades; we suggest putting it in "mydocuments" so its easy to find
2. Save the zipfile in the new Cyclopital3D folder.
3. Hover over the new file "C3DV\_Update," and right click on it, click "Extract All." The extraction wizard screen will appear, click "next." A dialog box will appear to save the new file name, put your cursor at the end of the suggested file name and backspace to erase the words "\C3DV\_Update," and click "next." Click "Finish."
4. Next, you will see a directory list that includes a folder named "LiveSuit;" double click on it. Navigate to the "LiveSuit.exe"(globe icon) and double click on it to execute the upgrade program; this action will create a desktop icon for LiveSuit and a window will appear on your screen. If a LiveSuit window doesn't appear look for the icon on the bottom right of your screen and double click on it (hover over the icons and their names should appear).
5. Click once on the left-most icon that looks like a yellow package. A directory list will appear, navigate to the Cyclopital3D folder and double click on it to open. Navigate down to the file named "v6000hdv.img" and double click on it.  
**Stop**, go to step 6.

### Step #2, Loading upgraded files to PMP unit #1:

6. Make sure PMP unit power switch is OFF, connect PMP unit to computer using a USB cable and be careful not to unplug the unit until instructed to do so.
7. Single click the second icon from the left, the "gears" icon. A dialog box will appear with jumbled text, click "yes" and the box will disappear. A new dialog box will appear that says "Found New Hardware" at the top; click the bubble next to "no, not this time" and click "next." Be patient, but if the new box doesn't appear click the "gear again." Another "Found New Hardware" dialog box will appear, click the bubble next to "install from list or specific location (advanced)," then click "next." Another dialog box will appear, uncheck the first box and check the second box "include this location in the search" and click "Browse" Find the new Cyclopital3D folder you created on your computer; navigate the directory to find and click on the file "UsbDriver" that is in the LiveSuite folder, click "ok" and "next." If another dialog box appears for hardware installation that says the program may not be compatible with XP, click "continue anyway," and wait...**Do not unplug PMP unit!**
8. The installation should proceed and you should see the progress bar filling moving after a few seconds. WAIT...it could take several seconds or minutes to see the next dialog box, do not interrupt the process, just wait... When load is complete, click "Finish." A dialog box may appear for LiveSuit with jumbled text in it, click "OK." **Do not unplug the PMP unit!**
9. The PMP unit will display a loading screen while updating.  
**\*\*DO NOT unplug unit until it turns off by itself- if you prematurely unplug the unit it could become permanently inoperable!** Wait for the screen on the PMP unit to turn off and wait at least 10 seconds before unplugging the USB cable.

# Cyclopital3D

## Update Procedures for PMP units using Windows XP OS (10/09)

**Loading Upgrade files to PMP unit #2** is much quicker and easier!

Connect 2<sup>nd</sup> PMP unit to your computer using a USB cable

Wait and watch the PMP unit screen; it should light up during the download process.

If a new dialog box appears, ignore it and click on the “gear” icon on the LiveSuite dialog box

Click “yes” on any dialog boxes that appear with jumbled text

Be patient, after several seconds the progress bar should start filling

The PMP units should turn on again can take several minutes before completing and turning off. Wait 5 minutes (to be safe) before unplugging PMP unit.

**\*\*Caution! Do not unplug prematurely or the PMP unit may become inoperable.**

Close the LiveSuit program by clicking on the “person” icon on the far right (X doesn’t do it).

### Step #3

#### Restoring default settings in PMP unit:

1. After unplugging USB cable from the PMP unit, turn on the power switches (both top and bottom) and you will a Chinese menu because the update has reset the default settings. You must now set the PMP units to show English and set some other parameters; if you have difficulty manipulating the menu in reverse you can remove the PMP units from the Viewer using the allen wrench/hex key wrench included with your Viewer. If the light “times out” just press one of the top arrows once to re-light it.
2. Language reset:
  - press the left arrow button on the top left of the PMP unit until it highlights the “wrench & monitor” icon under the “gear icon”
  - press the down button on the top right of the PMP until the “globe & wrench” icon is highlighted and press “enter”
  - press the down button for “english” and press enter.
3. Set auto power off timeout:
  - immediately after language reset, press up arrow to “auto off” icon and press enter
  - default is “always on,” use the up arrow to reset to 15 min and press enter.
4. Power saving settings:
  - press up arrow once to the “Power saving” icon and press enter, press enter again
  - press down arrow to set screen to level 5 for full brightness, press enter
  - press down arrow to highlight “screen close” icon and press enter;
  - press down arrow to “always on” and press enter for backlight to be always on
  - press left arrow button to exit settings mode
5. Reset Wallpaper:
  - press right arrow to go to “Photo” icon
  - find a photo you want to use as your wallpaper and click “enter,”
  - press enter again to see a menu of options
  - press enter on the “timeslot” icon and press enter again
  - press the down arrow to highlight “5s” and press enter
  - Press the left arrow to move back one menu
  - press the down arrow to highlight “switch mode” and press enter
  - press enter again to select “default”
  - press the left arrow to get back one menu
  - press the down arrow three times until “set wallpaper” is highlighted and press enter
  - press the left arrow to exit.
  - Turn PMP unit off.